



# Citrace® Hospital Disinfectant & Sanitizer



Effective on soft surfaces too!



## Eliminates microorganisms from fabrics, hard surfaces and more

Citrace® is formulated for broad-spectrum use on:

### Soft Surfaces

#### Kills 99.9% of Bacteria on Soft Surfaces in 30 Seconds

Citrace® is EPA-registered to decontaminate soft surfaces in just 30 seconds. Simply spray\* on high-touch soft surfaces in your facility, such as:

- Privacy curtains
- Upholstered furniture
- Cushions
- Lab coats†
- Linens†

Incorporate into your facility's daily cleaning protocols to help prevent the spread of microorganisms that can contribute to HAIs.

Incorporate into your facility's daily cleaning protocols to help prevent the spread of microorganisms that can contribute to HAIs.

#### Prevents Mold and Mildew on Fabrics

Citrace® inhibits the growth of mold and mildew on fabrics. Use on fabrics such as privacy curtains, drapes and upholstery. Repeat use regularly to prevent regrowth.

### Hard Surfaces

#### Disinfects Hard Surfaces in 5 Minutes

Citrace® kills 24 microorganisms on hard, nonporous surfaces in 5 minutes. Use on high-touch surfaces such as light switches, telephone receivers, remote controls and wheelchairs, as well as noncritical equipment like empty wastebaskets, supply carts and bathroom basins.

### Air

#### Kills Odor-Causing Bacteria

Citrace® destroys odors completely. While other products may just cover up odors, Citrace® eliminates the bacteria responsible, so odors don't come back. With a fresh citrus scent, it sanitizes the air in bathrooms and patient areas, as well as fabrics, drapes, and upholstered furniture.

\*Use as directed.

†Allow to air dry before use.

# Clorox Healthcare® Citrace® Hospital Disinfectant & Sanitizer

(EPA Reg. No 67619-29)

| Effective against   | Kill Time |
|---|-----------|
| <b>Bacteria</b>   |           |
| <i>Acinetobacter baumannii</i>  | 5 min     |
| <i>Enterobacter aerogenes</i>   | 5 min     |
| Vancomycin-resistant <i>Enterococcus faecalis</i> (VRE)                                       | 5 min     |
| Multidrug-resistant <i>Enterococcus faecium</i>   | 5 min     |
| ESBL-producing <i>Escherichia coli</i>  | 5 min     |
| <i>Klebsiella pneumoniae</i>  | 5 min     |
| Multidrug-resistant <i>Klebsiella pneumoniae</i>  | 5 min     |
| <i>Pseudomonas aeruginosa</i>   | 5 min     |
| <i>Salmonella enterica</i>  | 5 min     |
| <i>Staphylococcus aureus</i>  | 5 min     |
| <i>Staphylococcus aureus</i> (MRSA) (Methicillin-resistant)                                   | 5 min     |
| <i>Staphylococcus aureus</i> (CA-MRSA) (Community-associated Methicillin-resistant) (USA 400) | 5 min     |
| Multidrug-resistant <i>Staphylococcus aureus</i>  | 5 min     |
| Penicillin-resistant <i>Streptococcus pneumoniae</i> (PRSP)                                   | 5 min     |
| <b>Viruses</b>  |           |
| Coxsackie Type B3 Virus   | 5 min     |
| Hepatitis A Virus (HAV)   | 5 min     |
| Hepatitis B Virus (HBV) <sup>†</sup>  | 5 min     |
| Herpes Simplex Virus (HSV-1)  | 5 min     |
| Human Immunodeficiency Virus Type 1 (HIV-1)   | 1 min     |
| Influenza A Virus   | 5 min     |
| Respiratory Syncytial Virus (RSV)   | 5 min     |
| Rhinovirus  | 5 min     |
| Rotavirus   | 5 min     |
| <b>Fungi</b>  |           |
| <i>Trichophyton mentagrophytes</i> (Athlete's Foot Fungus)                                    | 5 min     |
| <b>TOTAL: 24 CLAIMS</b>   |           |

<sup>†</sup> Obtained via surrogate

\* Allow to air dry before use.

Based on EPA Master Labels as of November 2019.

Use as directed.

## More Spray Time

Citrace offers longer spray times than alternatives.

| BRAND                                 | SPRAYS/CAN RESULTS |                            |
|---------------------------------------|--------------------|----------------------------|
| <b>Citrace®, 14 oz.</b>               | <b>550</b>         | <b>The most spray time</b> |
| Professional Lysol® Brand III, 19 oz. | 375                | 32% less spray time        |
| Professional Amphyll® II, 13 oz.      | 273                | 50% less spray time        |

## Meets CDC and OSHA Standards

Citrace® meets CDC and OSHA bloodborne pathogens standards.

## Designed for use in healthcare settings, including:

- Dental offices
- Doctor's offices
- Hospitals
- Long-term care facilities
- Nursing homes

## Use in areas such as:

Patient and Exam Rooms

Waiting and Reception Areas

Public Restrooms



## Use for decontaminating and deodorizing high-touch, soft surfaces:

- Curtains
- Chairs
- Couches
- Lab coats\*
- Linens\*
- Mouse pads
- Rugs
- Upholstery

## Use for disinfecting high-touch, hard surfaces:

- Bed pans
- Carts
- Doorknobs
- Empty wastebaskets
- Light switches
- Remote controls
- Telephone receivers
- Walkers
- Wheelchairs

## Usage tips:

- Use Citrace® in adequately ventilated areas.
- For first-time use on soft surfaces, spot test in a small, inconspicuous area.
- For best results on hard and soft surfaces, apply product in a smooth zigzag motion, spraying mist evenly across surface.

## Product Information



### Clorox Healthcare® Citrace® Hospital Disinfectant & Sanitizer

Item No. 49100, 12/14 oz.



HEALTHCARE™

FROM CLOROX PRO™

For product resources and implementation tools, contact your Clorox sales representative or Call: 1-800-234-7700  
Visit: [www.CloroxHealthcare.com](http://www.CloroxHealthcare.com)  
Email: [healthcare@clorox.com](mailto:healthcare@clorox.com)

© 2019 Clorox Professional Products Company, 1221 Broadway, Oakland, CA 94612.